

G-S Hypo Adhesives

For Precision Work

Tips for using G-S Hypo Paper Cement

G-S Hypo Paper Cement

- Acid-free and lignin-free, archival quality, safe for photos
- A fast-drying cement, dries clear, stays clear
- Ideal for intricate paper projects with beads, metal, wire, glitter, rhinestones, ribbon, trim, or any decorative accessory
- Does not wrinkle paper
- Will not bond fingers
- A slightly more viscous cement (the formula needs to be thicker for the grab power required on more porous surfaces, such as paper)
- Due to the fact that G-S Hypo Paper Cement is thicker, it requires a bit more hand strength to get it started out of the tube
- To get an even flow of cement, move the tube slowly along the surface while squeezing evenly

All Hypo Adhesives

- Flatten the tube as it is used; do not roll
- Take care not to twist the tube, as twisting may cause the tube to crack
- Do not press down on the applicator when applying cement. Pressure can cause the precision applicator to become dislodged. Gently move the applicator along the surface while applying the cement.
- Place cap wire in applicator when not in use to stop the flow of cement out of the applicator. *Helpful hint:* Place applicator flat against finger to help guide the cap wire into the precision applicator.
- Always clean the precision applicator area and neck of tube with acetone or nail polish remover before closing the cap (rubbing alcohol can be used for G-S Hypo Cement). This will prevent drops of cement from sealing the cap to the tube.

Because the cement likes to keep flowing out of the applicator once it starts, here is a helpful hint when doing assembly work:

If you do not have time to replace the cap wire into the precision applicator between uses, keep an empty spice bottle in your work area, along with a small piece of sponge soaked in nail polish remover. After using the cement, set the tube "neck up" in the spice bottle and place the wet sponge over the precision applicator. This will stop the flow of cement and keep the applicator clean and ready for use.

408 St. Paul Street
PO Box 31091
Rochester, NY 14603-1091



Toll-Free: 800.295.3050
Phone: 585.295.0250
Fax: 585.232.3866



Web: www.gssupplies.com
e-mail: info@gssupplies.com