



## **G-S Hypo Fabric Cement** For Precision Work Guidelines / Recommendations

- For porous-to-porous or porous-to-non-porous surfaces
- Apply cement to surface and position immediately for permanent bonding.
- Ideal for fabric, beading, arts & crafts, balsa wood, paper, costuming, hem repairs, controlling frayed edges, appliqués, yarn, home décor and any decorative application.
- Fast drying. Dries clear, stays clear.
- Will not bond fingers.
- A slightly more viscous cement. The formula needs to be thicker to adhere to porous materials.
- Fabric applications: Pre-shrink fabric before use. Test on sample.
- Allow 24 hours before washing. Washing by hand recommended. Can be machine washed. Do not dry clean.
- Paper and Photo applications: Acid free and Lignin free.
- Due to the fact that G-S Hypo Fabric Cement is thicker, it requires a bit more hand strength to get it started out of the tube.
- To get an even flow of cement, move the tube slowly along the surface while squeezing the tube evenly.
- Clean or peel off any excess drops of cement on applicator before use.
- Flatten the tube as it is used; do not roll, twist or bend.
- Take care not to twist the tube, as twisting may cause the tube to crack.
- Do not exert pressure on the applicator when applying cement. Pressure can cause the precision applicator to become dislodged. Gently move the applicator along the surface while applying the cement.
- Place cap wire in applicator when not in use to stop the flow of cement out of the applicator. Helpful hint: Place applicator flat against finger to help guide the cap wire into the precision applicator.
- Always thoroughly clean the precision applicator area and neck of tube with acetone or nail polish remover before closing the cap. This will prevent drops of cement from sealing the cap to the tube.
- Store G-S Hypo Fabric Cement at room temperature. Do not refrigerate or freeze.
- Shelf-life: One year from date of purchase.

Because the cement tends to keep flowing out of the applicator once it starts, here is a helpful hint when doing assembly work: If you do not have time to place the cap wire into the precision applicator between uses, keep an empty spice bottle in your work area, along with a small piece of sponge soaked in nail polish remover. After using the cement, set the tube “neck up” in the spice bottle and place the wet sponge over the precision applicator. This will stop the flow of cement and keep the applicator clean and ready for use.

1150 University Avenue  
Suite 5  
Rochester NY 14607-1663

• Toll-Free 800.295.3050  
Phone 585.241.2370  
Fax 585.241.2375

• [www.gssupplies.com](http://www.gssupplies.com)  
[info@gssupplies.com](mailto:info@gssupplies.com)

• [www.toolsgs.com](http://www.toolsgs.com)